

UP AND DOWN BUTTONS

SET BUTTON

TEMPERATURE DISPLAY


USB OUTLET

BATTERY PROTECTION



BLUETOOTH® CONNECTION

COMPRESSOR SPEED



POWER ON/OFF BUTTON




POWER

1. Press & Hold  button for 3 seconds to turn fridge ON.
2. Press & Hold  button for 3 seconds to turn fridge OFF.


TEMPERATURE SETTING

1. Press **SET** for 5 seconds to select right zone.
2. Display FLASHES current temperature setting.
3. Press   to set temperature.
4. Display FLASHES 5 times then returns to display ACTUAL temperature.

BATTERY PROTECTION

1. Press  for 5 seconds until an audible "BEEP" then continue to press to select required setting (HIGH - MED - LOW).

COMPRESSOR SPEED

1. Press  for 5 seconds until an audible "BEEP" then continue to press to select required setting (MAX - NORM - ECO).